

Next steps for learning fun!

FCC Compliance Statement. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications to this unit not expressly approved by LeapFrog Enterprises, Inc., could void the user's authority to operate the equipment. CAN ICES-3 (B) / NMB-3 (B)

Environmental phenomena. The unit may malfunction if subjected to radio-frequency interference. It should revert to normal operation when the interference stops. If not, it may become necessary to turn the power off and back on, or remove and reinstall the batteries. In the unlikely event of an electrostatic discharge, the unit may malfunction and lose memory, requiring the user to reset the device by removing and reinstalling the batteries.

Impact de l'environnement. Une défaillance de fonctionnement de l'appareil peut survenir s'il est sujet à des interférences avec les fréquences radioélectriques. Le fonctionnement normal de l'appareil devrait reprendre avec l'arrêt des interférences. Si ce n'est pas le cas, il peut s'avérer nécessaire d'éteindre et rallumer l'appareil ou de retirer et réinstaller les piles. Dans l'éventualité peu probable d'une décharge électrostatique, un mauvais fonctionnement et une perte de mémoire de l'appareil peuvent se produire. L'utilisateur doit alors retirer et réinstaller les piles pour réinitialiser l'appareil.

Recycle. Find out how to recycle this product at leapfrog.com/recycle or call (800) 701-5327. For UK consumers, visit leapfrog.co.uk/recycle.



Learn & Groove™ Musical Mat
2+ years



Chat & Count Phone
18+ months



Musical Rainbow Tea Party
2+ years

CONSUMER SUPPORT

U.S. leapfrog.com/support
U.K. leapfrog.co.uk/support

Canada leapfrog.ca/support
Australia funtastic.com.au

WARRANTY INFORMATION

Limited warranty. Visit our website at www.leapfrog.com for full details of the warranty provided in your country.

Garantie limitée. Veuillez consulter notre site Web à l'adresse www.leapfrog.com pour obtenir l'intégralité des informations de garantie fournies dans votre pays.

TM & © 2016 LeapFrog Enterprises, Inc. All rights reserved. LeapFrog.com

For ages 2 years and up. Convient aux enfants à partir de 2 ans.
Item number 19303/ Part number 605-11884-A

Products sold separately and may not be available in all countries. Actual products may vary.



Melody the Musical Turtle™



Parent Guide

This guide contains important information. Please keep it for future reference.



Ahead.

Find out more at leapfrog.com

Features



Get Started

This toy can be played alone or with a friend. Slide the power switch to low or high volume.

How to Play

Select your play mode by sliding the mode switch. Next select one or two players by tapping the correct button when prompted. If in two-player mode, the gameplay stays the same; however, the toy will ask players to alternate turns.

123 Easy Mode

Follow the directions and answer questions based on colors/colours or numbers. Answer as many questions as you can before the music ends. When the music ends, get ready for the bonus round! (For example, turn the lights off as fast as you can!)

★ Challenge Level Mode

Watch the buttons light up and tap them as they create a sequence. See how many you can remember in a row. After receiving your score, get ready for the bonus round!

🎵 Music Mode

Tap the buttons as they light up. As you do, they will play a note. Try to guess the tune! After the toy provides the name of the actual song, get ready for the bonus round!

Battery Information. Requires 4 AA (called LR6 in some countries) alkaline batteries. Nécessite 4 piles alcalines AA (appelées LRO3 dans certains pays).

Battery Removal and Installation Instructions

1. Open the battery door with a Phillips screwdriver.
2. If used or dead batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
3. Install new batteries as shown in the polarity (+/-) diagram inside the battery compartment.
4. Replace battery door securely.

Battery Safety. Batteries are small objects and may pose a choking hazard for small children. Batteries must be replaced by an adult. Rechargeable batteries are to be removed from the toy before being charged, rechargeable batteries are only to be charged under adult supervision. Follow the polarity (+/-) diagram in the battery compartment. Promptly remove dead batteries from the toy to avoid leaking. Dispose of used batteries properly. Remove batteries for prolonged storage. Only batteries of the same or equivalent type as recommended are to be used.

- DO NOT** incinerate used batteries.
 - DO NOT** dispose of batteries in fire, as batteries may explode or leak.
 - DO NOT** mix old and new batteries or types of batteries (e.g., alkaline/standard).
 - DO NOT** recharge non-rechargeable batteries.
 - DO NOT** short-circuit the supply terminals.
- Rechargeable batteries are to be removed from the toy before being charged. Rechargeable batteries are only to be charged under adult supervision.

Sécurité relative aux piles. Les piles sont des objets de petite taille et peuvent constituer un risque d'étranglement pour les enfants en bas âge. Le remplacement des piles doit être effectué par un adulte. Les accumulateurs doivent être chargés uniquement sous le contrôle d'un adulte. Les accumulateurs doivent être enlevés du jouet avant d'être chargés. Respectez le schéma de polarité (+/-) reproduit dans le compartiment des piles. Enlevez rapidement les piles usagées du jouet pour éviter les fuites. Suivez les procédures adéquates pour vous débarrasser des piles usagées. Retirez les piles en cas de non-usage prolongé. Utilisez uniquement des piles ou accumulateurs du type recommandé ou d'un type équivalent.

- NE PAS** incinérer les piles usagées.
 - NE PAS** jeter les piles au feu car elles peuvent exploser ou fuir.
 - NE PAS** mélanger piles usagées et piles neuves, ni différents types de piles (c'est-à-dire alcalines/standard).
 - NE PAS** recharger des piles non rechargeables.
 - NE PAS** court-circuiter les terminaux d'alimentation.
- les accumulateurs doivent être chargés uniquement sous le contrôle d'un adulte. les accumulateurs doivent être enlevés du jouet avant d'être chargés.

For indoor, dry-location use only. Keep food and beverages away from product. Do not spill liquid of any kind on this product as it may render it inoperative. Clean with a slightly damp cloth (cold water). Do not use soap, detergent or other chemicals. Never submerge the unit in water. Allow to dry before re-use. Avoid prolonged exposure to extreme temperatures and direct sunlight. Avoid dropping the unit. Never try to dismantle it.

Utiliser uniquement en intérieur, dans des lieux secs. Tenir le produit à l'écart de la nourriture et des boissons. Ne jamais renverser un liquide sur ce produit car cela peut l'endommager ou en faire cesser son fonctionnement. Nettoyer avec un chiffon légèrement humide (utiliser de l'eau froide). N'utilisez pas de savon, de lessive, ou d'autres produits chimiques. Ne jamais immerger le produit dans l'eau. Éviter une exposition prolongée aux températures extrêmes et aux rayons du soleil. Éviter de laisser tomber le produit. Ne jamais essayer de le démonter.

⚠ **CAUTION:** Toy may contain flashes or patterns that may trigger photosensitive seizures.

⚠ **ATTENTION:** Les utilisateurs de ce jouet peuvent être victimes d'une attaque ou d'un évanouissement déclenché par les lumières ou les motifs clignotants (symptômes reliés à l'épilepsie).

⚠ **CAUTION:** Routinely check this toy for proper and safe condition. If there is any damage or broken parts, remove toy from use.

⚠ **ATTENTION:** Vérifiez régulièrement que ce jouet est en bon état et qu'il ne présente pas de danger. Dans le cas contraire (par exemple, s'il est cassé à certains endroits), tenez ce jouet hors de portée des enfants.

⚠ **CAUTION:** To be used under the direct supervision of an adult.

⚠ **ATTENTION:** Doit être utilisé sous la supervision directe d'un adulte.