



# Learning Up Rainbow Pal™




## Instruction Manual

This guide contains important information. Please keep it for future reference.

# INTRODUCTION

Thank you for purchasing **Learning Up Rainbow Pal™**! This colorful axolotl features 5 buttons that introduce letters, shapes, and colors in English and Spanish. The attachment loop lets you take this musical bilingual pal everywhere you go!



# INCLUDED IN THIS PACKAGE

- Learning Up Rainbow Pal™
- Quick Start Guide

## **WARNING**

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

## **NOTE**

Please save this Instruction Manual as it contains important information.

## **ATTENTION**

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.


## **NOTE**

Il est conseillé de conserver ce guide de démarrage rapide car il comporte des informations importantes.

# GETTING STARTED

## Battery Removal and Installation

1. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
2. Remove old batteries by pulling up on one end of each battery.
3. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box.(For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
4. Replace the battery cover and tighten the screw to secure.





## **WARNING:**

Adult assembly required for battery installation.  
Keep batteries out of reach of children.



## **ATTENTION :**

Les piles ou accumulateurs doivent être installés par un adulte. Tenir les piles ou accumulateurs hors de portée des enfants.

## **IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

## **RECHARGEABLE BATTERIES**

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

# PRODUCT FEATURES

## 1. Automatic Shut-Off

Press any button on the axolotl's tummy to turn the toy **On**. Press and hold the **Light-Up Music Button** for approximately 3 seconds to put the toy to sleep. To preserve battery life, **Learning Up Rainbow Pal™** will automatically shut off after approximately 30 seconds without input. The toy can be turned on again by pressing any of the buttons.

**NOTE:** If the toy powers down quickly while playing, we suggest changing the batteries.

## 2. Attachment Loop

Use the velcro **Attachment Loop** to secure the axolotl to baby's gear for on-the-go play.



# ACTIVITIES

## 1. Light-Up Music Button

Press the **Light-Up Music Button** to hear friendly axolotl sounds, phrases, learning songs and soothing music.



## 2. ABC Button

Press the **ABC Button** to hear the alphabet song and a fun phrase.



### 3. 123 Button

Press the **123 Button** to hear the numbers 1 through 5, calming exercises, and a number song.



### 4. Rainbow Button

Press the **Rainbow Button** to hear the axolotl ask about your favorite color and sing a song about colors.



### 5. English/Spanish Button

Press the **English/Spanish Button** to switch the responses of all of the buttons between English and Spanish.



# SONG LYRICS

## English Songs

### ABC Song

A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T, U, V, W, X, Y, Z

### Counting Song

Let's count to 5!

1, 2, 3, 4, 5!

### Rainbow Song

Red, Orange, Yellow, Green, Blue, and Purple

These are the colors of the rainbow!

Red, Orange, Yellow, Green, Blue, and Purple

These are the colors I know!

## Spanish Songs

### ABC Song

A, B, C, D, E, F, G, H, I, J, K, L, M, N, Ñ, O, P, Q, R, S, T, U, V, W, X, Y, Z

### Counting Song

¡Cuenta hasta cinco!

¡Uno, dos, tres, cuatro, cinco!

### Rainbow Song

Rojo, naranja, amarillo, verde, azul y morado.

Los colores del arcoíris.

Rojo, naranja, amarillo, verde, azul y morado.

Son los colores que ya se!

## TUNES

Clair de Lune by Claude Debussy

Twinkle, Twinkle, Little Star



## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. **Learning Up Rainbow Pal™** is surface washable only.

## TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit to sleep by pressing and holding the **Light-Up Music button** for approximately 3 seconds.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On** by pressing any button. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

## Environmental Phenomena

The unit may malfunction if subjected to radio-frequency interference. It should revert to normal operation when the interference stops. If not, it may become necessary to turn the power **Off** and back **On**, or remove and reinstall the batteries. In the unlikely event of an electrostatic discharge, the unit may malfunction and lose memory, requiring the user to reset the device by removing and reinstalling the batteries.

# Impact de l'environnement

Une défaillance de fonctionnement de l'appareil peut survenir s'il est sujet à des interférences avec les fréquences radioélectriques. Le fonctionnement normal de l'appareil devrait reprendre avec l'arrêt des interférences. Si ce n'est pas le cas, il peut s'avérer nécessaire d'éteindre et rallumer l'appareil ou de retirer et réinstaller les piles. Dans l'éventualité peu probable d'une décharge électrostatique, un mauvais fonctionnement et une perte de mémoire de l'appareil peuvent se produire. L'utilisateur doit alors retirer et réinstaller les piles pour réinitialiser l'appareil.

## NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### IMPORTANT NOTE:

If the problem persists, please call our Consumer Services Department at **1-800-701-5327** in the U.S. and Canada, or email [support@leapfrog.com](mailto:support@leapfrog.com). Creating and developing LeapFrog® products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

### Supplier's Declaration of Conformity

#### 47 CFR § 2.1077 Compliance Information

Trade Name: LeapFrog®  
Model: 6203  
Product Name: Learning Up Rainbow Pal™  
Responsible Party: LeapFrog Enterprises, Inc.  
Address: 2200 Powell St., Suite 500  
Emeryville, CA 94608  
Website: [leapfrog.com](http://leapfrog.com)

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.



***Visit our website for more  
information about our products,  
downloads, resources and more.***

***leapfrog.com***

***Read our complete warranty policy online at  
leapfrog.com/legal***

A subsidiary of VTech Holdings Limited.

© 2024 LeapFrog Enterprises, Inc.

All rights reserved.

IM-620300-000

Version:0