

## APP LEARNING TOY



**Learn to Write**  
with **Mr. Pencil™**



**Unlock an interactive adventure with  
the Mr. Pencil™ Stylus & App.**



### **Parent Guide & Instructions**

This guide contains important information. Please keep it for future reference.

## **Learning Path™**

### **Discover your custom learning roadmap!**

- Learning solutions to help kids reach their potential.
- Activities and printables for every age and stage.
- Educational insights for parents and kids.



**Visit [leapfrog.com/learningpath](http://leapfrog.com/learningpath)**

The LeapFrog® Learning Path is not available in all countries.

## Fun next steps on your child's path to learning!



### **Creativity Camera Protective Case & App**

2+ years



### **Scribble & Write**

3+ years



### **Read With Me Scout**

2+ years

Get more ideas to support  
your child's learning at:  
**[leapfrog.com/learningpath](http://leapfrog.com/learningpath)**

Products sold separately, and may not be available in all countries. Actual products may vary.

## Learning Skills

# Go on a writing adventure through Doodleburg!

### Learn to write letters, numbers and shapes

Learn with 85+ writing activities: upper- and lowercase letters, numbers 1-20, and 12 shapes.

### Creativity comes to life

Help Dot & Dash decorate Doodleburg and prepare dozens of parade floats for Art Appreciation Day.

There are lots of exciting, interactive things going on in Doodleburg so use your Mr. Pencil™ stylus to explore the app.

### Get instant feedback

Learn how to form letters, numbers and shapes with interactive stroke guidance.



## Instructions for Play



### Getting Started



1. Download Learn to Write with Mr. Pencil™ App free (no purchase necessary) from the App Store<sup>SM</sup>.



2. Tap on the Learn to Write with Mr. Pencil™ Writing App icon on your iPhone®, iPod touch® or iPad® to launch the app.



3. At the unlock screen, touch the eraser end of the Mr. Pencil™ Stylus to the screen to unlock additional learning and interactive activities as prompted by the app.

### Write

Learn to write the letters of the alphabet, numbers and shapes with stroke-by-stroke guidance. Each writing activity allows three practice/practise tries, but children can trace any letter, number and shape as many times as they desire. The easy-grip Mr. Pencil stylus also helps to teach proper pencil grip to build strong handwriting skills.



### Play

Start to play and learn in four unique locations in the town of Doodleburg. Each time a writing activity is completed, look for new decorations and animations that come to life! To unlock all activities and locations in Doodleburg, use Mr. Pencil's eraser to stamp special spots at the Unlock Screen. The app will provide instructions to guide you through this process.

### Explore

Unlock and explore the entire town of Doodleburg, from the Firehouse to the Spooky Mansion, there is fun to be had around every corner as you help Dot and Dash in the preparation for Doodleburg's Art Appreciation Day. Complete the learning activities to build towards a fabulous display of 24 different parade floats through the streets of Doodleburg.



## Compatibility

LeapFrog's Learn to Write with Mr. Pencil™ Stylus & App for iPhone®, iPad®, and iPod touch®.


### Important Information:

- Adult download of App is required.
- Periodically check your Apple device for damage or cracks. Do not use if device is damaged or broken. Follow instructions for use, care and cleaning.

## Instructions for Care

### FOR DRY, INDOOR-LOCATION USE ONLY

Keep food and beverages away from product. Never spill liquid of any kind on this product as it may cause damage or render the device inoperative. Clean with a slightly damp cloth (cold water). Do not use soap or detergent. Never submerge the unit in water. Avoid prolonged exposure to extreme temperatures and direct sunlight. Avoid dropping the unit. Never try to dismantle it.

 **CAUTION:** Routinely check this toy for proper and safe condition. If there is any damage or broken parts, remove toy from use.

 **ATTENTION :** Vérifier régulièrement l'état et le fonctionnement de ce jouet afin d'en garantir la sécurité. S'il est cassé ou endommagé, même partiellement, ranger ce jouet hors de portée des enfants.

 **CAUTION:** To be used under the direct supervision of an adult.

 **ATTENTION :** Doit être utilisé sous la présence directe d'un adulte.

 **WARNING:** CHOKING HAZARD - Small Parts. Not for children under 3 years.

 **AVERTISSEMENT :** RISQUE D'ETOUFFEMENT - Petits éléments risquant d'être ingérés. Ne convient pas aux enfants de moins de 3 ans.

 **NOTICE:** LeapFrog is not responsible for any damage to iPhone, iPad or iPod touch.

 **NOTE:** LeapFrog n'est pas responsable pour les dommages causés à iPhone, iPad ou iPod touch.

## Troubleshooting

### Symptom

The app does not respond.

### Try This

- Confirm the Apple device is turned on.
- Make sure the Apple device is properly charged.
- The tip of the Mr. Pencil Stylus must be touching the screen on the device.
- Make sure the app is correctly downloaded. For additional help, visit the Support section in the iTunes App Store.

Additional content areas and activities in the app do not launch.

- When you use the eraser as a stamp, make sure that the flat part of the eraser is in contact with the device screen.

**U.S. Consumer Service Contact:** Visit our U.S. Consumer Support website at [www.leapfrog.com/support](http://www.leapfrog.com/support) 24 hours a day.

**Canada Consumer Service Contact:** Visit our Canada Consumer Support website at [www.leapfrog.ca/support](http://www.leapfrog.ca/support) 24 hours a day.

**U.K. Consumer Service Contact:** Visit our U.K. Consumer Support website at [www.leapfrog.co.uk/support](http://www.leapfrog.co.uk/support) 24 hours a day.

**Australia Consumer Service Contact:** Please submit questions to our support staff via email at [info@funtastic.com.au](mailto:info@funtastic.com.au).

**LIMITED WARRANTY:** Subject to a limited three (3) month warranty. Visit our website at [www.leapfrog.com](http://www.leapfrog.com) for full details of the warranty provided in your country. LeapFrog shall not be liable for any incidental or consequential damages for the breach of any warranty on this product. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

**GARANTIE LIMITÉE :** Ce produit est soumis à une garantie limitée de trois (3) mois. Veuillez consulter notre site Web à l'adresse [www.leapfrog.com](http://www.leapfrog.com) pour obtenir l'intégralité des informations de garantie fournies dans votre pays. LeapFrog ne sera pas tenu responsable des dommages consécutifs ou indirects induits par la violation de toute garantie sur ce produit. Certaines juridictions n'autorisant pas l'exclusion ou la limitation des dommages consécutifs ou indirects, ni même la limitation de la durée des garanties implicites, il est donc possible que les limitations ou exclusions ci-dessus ne s'appliquent pas à votre cas.

Apple, iPad, iPhone and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple, Inc.

TM & © 2013 LeapFrog Enterprises, Inc. All rights reserved.

## leapfrog.com

Recommended for children 3+ years.  
Convient aux enfants à partir de 3 ans.

Item number: 19235  
Part number: 605-12002-A