



Sweet Treats Learning Café™




RctgpvÄ"l wlf g

This guide contains important information. Please keep it for future reference.

91-003377-002 (US)

KP VT QF WE VK QP

Thank you for purchasing the **Sweet Treats Learning Café™**. Place the cups in the coffee machine and watch them fill while learning about sizes. Press the order button to hear customer orders based on sizes, shapes, colors and numbers. Follow the directions to complete the customer orders and become an expert barista.



PACKING LIST

- One **Sweet Treats Learning Café™**
- One large coffee cup
- One small coffee cup
- Two plates
- One milk pitcher
- One pastry plate
- One sugar bowl
- One sugar spoon
- One circle donut
- One heart cookie
- One triangle cake
- One parent's guide

PACKING MATERIALS

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

PLEASE KEEP

Please keep this parent's guide as it contains important information.

FOR YOUR CHILD'S SAFETY

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.


PLEASE KEEP

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

I GVVK P I "UVCT VGF

DC VVGT ["K UVC NNC VKQ P

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit.
3. Use a screwdriver to loosen the screw and open the battery cover.
4. Install 3 new AA (AM-3/LR6) batteries into the battery box as illustrated. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



DC VVGT ["P QVKE G

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision


O KJG"GP "I C T F G

- Utilisez de nouvelles piles alcalines pour une performance maximale.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mélanger différents types de piles ou d'accumulateurs, ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas utiliser des piles ou des accumulateurs endommagés.
- Mettre en place les piles ou les accumulateurs en respectant les polarités + et -.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -).
- Enlever les piles ou les accumulateurs usagés du jouet.
- Retirer les piles ou les accumulateurs en cas de nonutilisation prolongée.
- Ne les jeter ni au feu ni dans la nature.
- Ne pas tenter de recharger des piles non rechargeables.
- Enlever les accumulateurs du jouet pour les recharger.
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.

RT QF WE V"HGCVWT GU


30' Qp1Qh1Xq rwo g'E qpvtqrUy kwej

Slide the **On/Off/Volume Control Switch** to turn the toy on and select the volume.




40'O ci ke"E wr u

Fill the **Small Coffee Cup** or **Large Coffee Cup** by placing it on the **Cup Sensor**. Push down until the **Dispenser Light** goes on and stays on. Select a **Beverage Button**, then press down on the **Star Button** on the top of the machine to make the cup magically fill. If the cup is "full," reset it by pushing down the "liquid" with your fingers or by placing the cup upside down on the blue nub on the top left side of the machine.



50'Qtf gt"Dwvqp

Press to receive imaginary customer orders.



6 0'O wuke"Dwvqp

Press to hear one of four learning songs.



70'Uvgco gt"Dwvqp"
Press to hear steamer sounds.



80'Vgo r gtcvwtg"F kcn
Turn dial to select a temperature and
hear corresponding brewing sounds.




90'l tkpf gt"Dwvqp"
Press the **Grinder Button** to pretend to
grind coffee beans.



C E V X W [

Qtf gt"Wr
Press the **Order Button** to hear imaginary
customer orders. Fill the requests to hear
rewarding sounds.



E C T G" ("O C K P V G P C P E G

1. Keep the toy and accessories clean by wiping them with a slightly damp cloth.
2. Keep it out of direct sunlight and away from direct sources of heat.
3. Remove the batteries when not using it for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

VT QWDNGUJ QQVKP I "

If for some reason the program/activity stops working, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **ON**. The unit will now be ready to play again.
5. If the unit still does not work, replace with an entire set of new batteries.

Gpxktqpo gpvcn'r j gpqo gpcO'

The unit may malfunction if subjected to radio-frequency interference. It should revert to normal operation when the interference stops. If not, it may become necessary to turn the power **OFF** and back **ON**, or remove and reinstall the batteries. In the unlikely event of an electrostatic discharge, the unit may malfunction and lose memory, requiring the user to reset the device by removing and reinstalling the batteries.

Ko r cev" f g "Ä gpxktqppgo gpvO'

Une défaillance de fonctionnement de l'appareil peut survenir s'il est sujet à des interférences avec les fréquences radioélectriques. Le fonctionnement normal de l'appareil devrait reprendre avec l'arrêt des interférences. Si ce n'est pas le cas, il peut s'avérer nécessaire d'éteindre et rallumer l'appareil ou de retirer et réinstaller les piles. Dans l'éventualité peu probable d'une décharge électrostatique, un mauvais fonctionnement et une perte de mémoire de l'appareil peuvent se produire. L'utilisateur doit alors retirer et réinstaller les piles pour réinitialiser l'appareil.

IMPORTANT NOTE:

If the problem persists, please call our Consumer Services Department at **1-800-701-5327** in the U.S. or email support@leapfrog.com. Creating and developing LeapFrog® products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAN ICES-3 (B)/NMB-3(B)

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



CLASS 1
LED PRODUCT

***For warranty information, please visit
leapfrog.com/warranty.***



***Visit our website for more
information about our products,
downloads, resources and more.***

leapfrog.com

LeapFrog Enterprises, Inc.,
a subsidiary of VTech Holdings Limited.
TM & © 2017 LeapFrog Enterprises, Inc.

All rights reserved.
91-003377-002 (US)